



- Note:
- Preformed Joint Sealant should be wrapped tightly around outside corners.
 - Sufficient amount of adhesive/sealant must be used to ensure that the extrusion remains in place until the adhesive has cured.
 - If necessary, adhesive tape may be used to hold the extrusion in place until the adhesive/sealant has set up.
 - An alternate solution would be an outside corner butt joint.