



Parapet Cap Splice Application

- 1.) Apply adhesive/sealant to parapet cap as usual
- 2.) Install preformed joint sealant allowing for adequate drip edge